

How to properly install and use our Push pins

The push pins should be installed upside down, through the inside of the insulation, into the collar holes. This can be done even if you have a steel back panel.

- Cut your collar opening and place the collar where you want it.
- Push some starter holes into the insulation with a small tool to mark where the pins need to be placed.
- Remove collar and then push the pins through the underside of the molded insulated back.
- Place the collar back on the insulation and line up the holes with the push pins. Push the pins all the way through the collar.

When a steel back panel is underneath the insulation, you will need to get the pin in between the two. This is easily done.

Do not attempt to put the push pin thru the holes in the steel back panel, they will NOT fit.

